

Module for emergency stop, gate monitoring, Electro-sensitive protection devices (ESPE) and magnetic safety sensor

Main functions
- Single or dual channel input circuit
- Choice between automatic start, manual start (CS AR-05 only) or monitored start (CS AR-06 only)
- Connectible to ESPE, to electromechanical contacts or to magnetic safety sensor
- Output contacts:
  3 NO safety contacts,
  1 NC auxiliary contact
- Supply voltages:
  24 VAC/DC, 120 VAC, 230 VAC

Utilization categories
Alternate current: AC15 (50...60 Hz)
Ue (V) 230
Ie (A) 3
Direct current: DC13 (6 operations/minute)
Ue (V) 24
Ie (A) 6

Markings, quality marks and certificates:

Approval UL: E131787

Complying with the requirements requested by:
Low Voltage Directive 2006/95/EC,
Machinery Directive 2006/42/EC,
Electromagnetic Compatibility 2004/108/EC

Technical data

Housing

Made of polyamide PA 6.6 self-extinguishing, class V0 (UL94)	
Protection degree:	IP40 (housing), IP20 (terminals)
Dimensions:	see page 4/141, shape A

General data

Safety category:	category 4 according to EN 954-1
Ambient temperature:	-25°C...+55°C
Mechanical endurance:	>10 millions of operations
Electrical endurance:	>100.000 operations
Pollution degree:	outside 3, inside 2
Rated impulse with stand voltage (Uimp):	4 KV
Rated insulation voltage (Ui):	250 V
Over-voltage category:	III
Weight:	0,3 Kg

Power supply

Rated operating voltage (Un):	24 VAC/DC; 50...60 Hz 120 VAC; 50...60 Hz 230 VAC; 50...60 Hz
Max residual ripple in DC:	10%
Supply voltage tolerance:	±15% of Un
Rated power consumption AC:	< 5 VA
Rated power consumption DC:	< 2 W

Control circuit

Protection against short circuits:	resistance PTC, Ih=0,5 A
Operating time of PTC:	intervention > 100 ms, reset > 3 s
Max input resistance:	≤ 50 Ω
Current for each input:	30 mA
Min. period of start impulse t_{MIN}:	250 ms
Operating time t_A:	200 ms
Releasing time t_{R1}:	15 ms
Releasing time in absence of power supply t_R:	70 ms
Simultaneity time t_C:	infinite

In conformity with standards:
IEC 60947-1, EN 60947-1, IEC 60204-1, EN 60204-1, EN ISO 13849-1, EN 999, EN 1037, EN ISO 12100-1, EN ISO 12100-2, EN ISO 13850, IEC 529, EN 60529, EN 61000-6-2, EN 61000-6-3, EN 62326-1, EN 60664-1, UL 508, CSA C22.2 n° 14-95

Output circuit

Output contacts:	3 NO safety contacts 1 NC auxiliary contact
Contacts type:	forced guided contacts
Contacts material:	silver alloy, gold plated
Max switching voltage:	230/240 VAC; 300 VDC
Max switching current per contact:	6 A
Conventional free air thermal current Ith:	6 A
Contacts resistance:	≤ 100 mΩ
Contact protection fuse:	6 A
The number and the load capacity of output contacts can be increased by using expansion modules or contactors:	see page 4/135 - 4/139

Code structure

CS AR-05V024

Kind of start

05	manual or automatic start
06	monitored start

Kind of connection

V	screw terminals
M	connector with screw terminals
X	connector with spring terminals

Supply voltage

024	24 VAC/DC	±15%
120	120 VAC	±15%
230	230 VAC	±15%

Data type approved by UL

Rated operating voltage (Un):	24 VAC/DC; 50...60 Hz 120 VAC; 50...60 Hz 230 VAC; 50...60 Hz
Rated power consumption AC:	< 5 VA
Rated power consumption DC:	< 2 W
Max switching voltage:	230 VAC
Max switching current per contact:	6 A
Utilization category	C300

Notes:
- Use 60° or 75 °C copper (Cu) conductor and wire size No. 30-12 AWG.
- Terminal tightening torque of 5-7 Lb-In.
- Only for 24 VAC/DC version, supply from remote class 2 source or limited voltage and limited energy.

Safety module CS AR-05-06

Terminals layout



Internal wiring diagram



Operation diagrams

Configuration with automatic start



Configuration with monitored start



Configuration with manual start



Legend:

t_{MIN}: Min. period of start impulse
t_C: Simultaneity time
t_A: Operating time
t_{R1}: Releasing time
t_R: Releasing time in absence of power supply

Note:
The configurations with one channel are obtained taking into consideration only the CH1 input. In this case it is necessary to consider the t_{R1} time referred to CH1 input, the t_R time referred to the supply, the t_A time referred to CH1 input and to the start, and the t_{MIN} time referred to the start.

Inputs configuration

Electro-sensitive protection devices ESPE

Input configuration with manual start



Emergency stop

Input configuration with manual start



The diagram does not show the exact position of clamps in the product

Automatic start (CS AR-05 only)

As regards the indicated diagrams, in order to activate the module with the automatic start, it is necessary to short the start button between S12 and S34 terminals.



Monitored start

Use the CS AR-06 module following the diagram for the manual start.

Gate monitoring and safety magnetic sensors.

The safety module can control both emergency stop circuits, gate monitoring circuits or safety magnetic sensors. Replace the emergency stop contacts with switches contacts or with the sensors contacts.